

# TYRE CHANGER

## TC-513A



### INSTRUCTION & MAINTENANCE MANUAL



Read this entire manual carefully and completely  
before installation or operation of the tire changer

# TYRE CHANGER INSTRUCTION MANUAL

INDEX	PAGE
1. Introduction:.....	2
2. Safety Warnings:.....	2
3. Technical data.....	3
4. Transport:.....	3
5. Unpacking & Inspection:.....	3
6. Workplace requirements:.....	3
7. Position and installation:.....	4
8. Electricity and Pneumatic connections:.....	4
9. Adjusting operation:.....	4
10. Help Arm 006.....	6
10.1 Technical Data.....	6
10.2. Safety Regulations.....	6
10.3. Installation.....	6
10.3.1. Transport.....	6
Move the device with a forklift truck as illustrated in Fig 8. ....	6
10.3.2. Unpacking.....	6
10.3.3. Workplace Requirement.....	6
10.3.4 Assembly.....	6
10.4.Operations.....	7
10.4.1. Fixing the Tire.....	7
10.4.2. Demounting the Tire.....	7
10.4.3. Mounting the tire.....	8
11. Inflating the tire :.....	8
12. Moving machine:.....	8
13. Maintenance:.....	8
14. Trouble shooting table:.....	10
14.Spare parts ordering guide.....	10
16. Vulnerability consumable spare parts list.....	11
17. Exploded drawing:.....	12
air cylinder.....	错误! 未定义书签。
18. Circuit diagram:.....	23
19. Pneumatic drawing:.....	23

# Tyre Changer

## Warning

This instruction manual is important for the machine, please read carefully before installation and use; also it is important for safe use and machine maintenance of machine. Please keep this manual properly in order to further maintenance of the machine.


## 1. Introduction:

Application Range: The automatic tyre changer is especially designed for demounting / mounting tyres from wheel rims.

**Caution:** Please use the machine only for purpose for which it is designed, don't use it for other purposes.

Manufacturer shall not be liable for any damage or injury caused by failure to comply with these regulations.

**Safety regulation:** Use of this machine is especially reserved to trained and qualified professional persons, those who already read the introduction manual carefully, or someone have the experience for operating similar machinery. Any changes and beyond the scope of use on this machine without manufacturer's permission or do not according to the manual, may cause the malfunction and damage to machine, manufacturer can cancel warranty coverage for above. If some parts are damaged due to some reason, please replace them according to the spare parts list. (Attention: warranty is one year after manufactures' delivery date; warranty excludes the easy-broken parts).



## 2. Safety Warnings:

- 01 Don't put hands under the Mounting head/demounting head during operation;
- 02 Don't put hands between the jaws during operation;
- 03 Don't put hands in the tyre bead when demounting the tyre;
- 04 Make sure and to check the system is equipped with a good grounding circuit;
- 05 Don't put feet between the Bead Breaker shovel and the body during operation;
- 06 Warning instruction

Security warning labels

Caution:

When **the security warning labels are defaced or off, please recovery them in time!**

**Do not allow to operate when the security warning labels are missed or imperfect.**

**Do not allow to set any objects to obscure the security warning labels.**

Clients can self-set the warning labels (as right picture show) at any necessary positions.



### 3. Technical data

External locking rim dimensions	10~21 "
Internal locking rim dimensions	12~24 "
Max. Wheel diameter	1040mm ( 41 " )
Max. Wheel width	355mm(16 " )
Working Pressure	8-10bar
Power supply	110V (1ph)/ 220V (1ph)/ 380V (3ph)
Optional Motor power	0.75/0.55/1.1 kw
Max. Rotating Torque (Turntable)	1078 Nm
Overall Dimension	960mm*760mm*930mm
Noise Level	<75dB

Remark:

**Rim dimensions defined at above table are based on the iron wheel rims. Aluminum rims are thicker than the iron wheel rims, so here above rim dimensions are just for the reference.**

Here above machine versions can be equipped with Rapid Tire Inflation Device (client optional device), IT-suffix version, accessory details can be found at the IT-suffix version diagram.

### 4. Transport:

When transporting, the machine should be with original package and placed according to the mark on the package. For the already packaged machine should be handled with a corresponding tonnage forklift for loading and unloading. The location to insert the fork feet shown as **Fig 1**

### 5. Unpacking & Inspection:

Pull out the nail which is nailed on the plate with tip jaw; unpack the carton and plastic cover. Check and make sure all parts shown on the spare parts list are included. If any parts are missing or broken, please do not use the machine and contact the manufacturer or dealer ASAP.




Fig 1




Fig 2




Fig 3

### 6. Workplace requirements:

Choose workplace in compliance with safety regulations. Connect power supply and air source according to manual and workplace must have good air condition; in order to make the machine run well, its workplace requires at least clear space from each wall shown as **Fig 2**. If installing it outdoor, it must be protected by roof against rain and sunshine.

Warning: the machine with motor must not be operated in explosive atmosphere.

## 7. Position and installation:

### 7.1 Install the column (accessories details refer to the exploded drawing)

- 1) Tools preparation
- 2) Place the tilting seat (3, Fig 3) on the body (1, Fig 3) with 4 bolts (M12), push air hose (2, Fig 3) through the hole of the column. Tighten 4 self-locking nut (8, Fig 3).
- 3) Insert screw (9, Fig 3) into the holes of both column and tilting cylinder shaft (11, Fig 3), tighten it with self-locking nut (10, Fig 3).
- 4) Unscrew the two bolts on the left cover and remove the cover, connect air hose (2, Fig 3) previously mentioned to the side holes which control the tilting 5-way valve. Fix the left cover.
- 5) Fix the plastic cover (7, Fig 3) with two bolts (4, Fig 3).
- 6) Mount the plastic back cover (5, Fig 3) on the column with screw (6, Fig 3).



## 8. Electricity and Pneumatic connections:

Warning: Before installation and connection, check to be sure that the electricity power supply corresponds to the machine technical data. All the installation of electric and pneumatic devices must be operated by a professional electrician.

Connect the compressed air connector which is on the machine right side with compressed air system. The electric grid that the machine connects to must have fuses protection device and good outer cover grounding protection. Install the leakage automatic air switch on the main power supply, leakage current is set at 30A

Caution: No power plug for this machine, the user should self-connect one power plug no less than 16A as well as in line with the machine voltage. Or directly connect with the power supply **according to the above requirements**.


## 9. Adjusting operation:




Tilting pedal (H)



Turntable Rotation pedal (Z)



Jaws open and close pedal(V)



Bead Breaker pedal(U)

Please note: below operation refer to **Fig 4**

Tread the Turntable Rotation Pedal (Z), Turntable (Y) clockwise rotation;

Lift up the Turntable Rotation Pedal (Z), Turntable (Y) counterclockwise rotation.

Tread Bead Breaker Pedal (U), Bead Breaker shovel (R) compress; release Bead Breaker Pedal (U), Bead Breaker shovel (R) back to original position.

Tread totally down Jaws open and close Pedal (V), four clamps (G) on the turntable open; Tread again, four clamps (G) close. When the pedal is in the middle position, the four clamps stop moving.

Depress pneumatic locking button (K) to lock the Slide arm (N) and Vertical arm (M).

Tread the Bead Breaker pedal (H), the tilting column (C) backwards down; depress again, the tilting column return.

Tyre changer operation is consisted of three parts:

- 1) Demounting the tyre bead
- 2) Demounting the tyre
- 3) Mounting the tyre

Caution: Before any operations, don't wear loose clothing and wear protective hat, gloves, and skid-proof shoes. Ensure to exhaust the air in the tyre completely, and remove all the wheel weights from the rim.

#### 9.1. Breaking the tyre bead:

Ensure to exhaust the air in the tyre completely, place the tyre against the rubber buffer (S). Bring the shovel (F) against the bead about 10mm from the edge of the rim shown as **Fig 5**. Depress Bead breaker Pedal (U) to push paddle into tyre. Repeat the above operations on different positions around the tyre and both sides of tyre until tyre bead is released completely.




Fig 5

#### 9.2. Demounting the tyre :

Ensure to remove all the weights on the wheel rim and to exhaust the air in the tyre completely before this operation. Apply lubricating grease (or similar lubricant) around the tyre bead. Without the lubricant may lead to badly wear and tear on tyre.

Clamp the wheel methods shown as below regarded to the ruled dimension:

a- to clamp the wheel from outside:

Depress the Jaws open and close Pedal (V) halfway down to middle, positioning for the four clamps (G) by reference scale on the Turntable (Y); put the tyre on turntable, hold the rim, and depress the Jaws open and close Pedal (V) until the wheel is secured by the jaws.

b- to clamp the wheel from inside:

Positioning for the four clamps (G) and let them all closed. Put the tyre on the turntable and depress the Jaws open and close Pedal (V) to open the clamps thereby lock the wheel in place.

Caution: Check to make sure the wheel firmly secured by the four clamps before next step.

Lower the Vertical Arm (M) until the Mounting head/demounting head (I) rests next to the edge of the rim, flip pneumatic locking button (K) to lock the Vertical Arm (M) and Horizontal arm in position, and control the distance from Mounting head/demounting head to the edge of wheel rim about 2-3 mm. Insert the Lifting Lever (T) between the tyre bead and the front section of the mounting head/demounting head (I), and move the tyre above the mounting head/demounting head as shown as **Fig 6**.




Fig 6

Caution: Chains, bracelets, loose clothes and anything else close to the rotating parts will bring danger to the operator. With the Lifting Lever held in position, depress the Turntable Rotation Pedal (Z), rotate the Turntable (Y) in a clockwise direction until the tyre is completely separated from the wheel rim.

For the other side tyre demounting, keep using the lifting lever to lift the tyre, make the other side tyre separated from the wheel rim. Depress the Tilt pedal (H), the column backward down, take out the tyre.

#### 9.3. Mounting the tyre :

Caution: Check to make sure that the tyre and the wheel rim are of same size before mounting the tyre.

To avoid any damage on type, lubricate the tyre bead and the wheel rim with the lubrication recommended by manufacturer. Put on the tyre and check the situation.

Caution: When clamp the wheel rim, don't put your hands on the wheel rim to avoid injury during this operation.



Fig 7

Lock the Hexagonal Vertical Mounting Arm, put the tyre on the rim, let the Rocker Arm back to place as demounting the tyre. And let one side of tyre down bead above the rear section of the Mounting head/demounting head, the other side under the front section of the Mounting head/demounting head. Suppress the tyre with hands or help arm, and then spin the turntable for mounting the tyre down bead.

Repeat the above operation for mounting the tyre up bead. (Fig 7)

## 10. Help Arm 006

The help arm 006 is an auxiliary device for tire changer, it is used to help to demount and mount tires.

**Before any operation of this machine, the operator is requested to read the manual carefully. Do not attempt any operations that are not stated in it. Manufacturer will not be responsible for any injury or damage caused by improper operation. Please keep the manual handy for consulting.**

### 10.1 Technical Data

Work Pressure	8~10 bar
Weight	100kg
Package dimension	1550*310*550mm
Noise Level	LpA<75dB



### 10.2. Safety Regulations

**This device is especially reserved to trained professional personnel or somebody who has experiences on mechanical operation and read this manual carefully. This device must be used together with our tire changers, we are not sure it can work with others. Manufacturer won't be responsible for any unauthorized modification.**




Fig 8

### 10.3. Installation

#### Notice!

The installation of this auxiliary device should be done by professional personnel. Before assembly, disconnect the device from power supply and air source.

#### 10.3.1. Transport

**Move the device with a forklift truck as illustrated in Fig 8.**

#### 10.3.2. Unpacking

When unpacking, check and make sure all parts shown on the packing list are included. If any parts are missing or broken, please call the manufacturer or the dealer asap. Please keep the package out of children's reach.

#### 10.3.3. Workplace Requirement

**Fig 9** shows the minimum distance (cm) from walls after assembly this auxiliary device. Please choose the right place to install it.




图 9

#### 10.3.4 Assembly

- 1) Disconnect the tire changer from power supply and air source.
- 2) In the area of "1", fixed the auxiliary arm 006 in the corresponding position with proper bolt.
- 3) Connect the air hose to the corresponding joint through the rear hole of the body. in the area of "1"




图 10




图 11

## 10.4. Operations

Mounting and demounting big flat tire is difficult work. By the help of 006 help arm to mount/demount the tire from the tire bead will make the operation easier. It is a good helper for tire changer.

### 10.4.1. Fixing the Tire

Loosen the bead according to the manual. Clamp the tire from outside, tread the corresponding pedal to open the jaws;

Put the tire on the turntable; Tread the corresponding pedal to close the jaws until they near the rim.

### 10.4.2. Demounting the Tire

-1. Generally speaking, tire is very tight. Loosen the beads with the tire pressing head first (or using the bead breaker if it too tight to loosen).

Pull out the Hexagonal horizontal arm; let the tire pressing roller above the tire without collision.

Lower the tire pressing roller lower with the switch handle to press the tire. Tread the pedal to rotate the turntable. Loosen the bead during this procedure. (Fig 11)

**Caution:** Lubricate the tire pressing head (upper) and the bead before the operation.




图 12




图 13



图 14

### -2. Demounting the upper bead

**a-** Move the mounting head near the edge of the rim, rotate the tire pressing arm to move the tire pressing block above the tire, press the switch handle to depress the tire, and insert the lifting lever in the clearance between the tire and the rim, then hang the bead on the mounting head. (Fig 12、 13)

**b-** Raise the auxiliary arm, rotate the tire pressing head to the opposite. Press the tire with the switch handle to create enough space.

**c-** Tread the power supply pedal to rotate the turntable. With the help of the tire pressing head, the upper tire bead is detached.

d- Raise the help arm to move the tire pressing block to its non-working position.

### -3. Demounting the bottom bead

Turn the roller support and move it under the tire, but don't touch it with the rim. ; (Fig 13) Tread the power supply pedal to rotate the turntable, meanwhile, lift help arm gradually to loosen tire and completely demount the bottom bead.

**Caution: The roller support can't be used for all tires, some tires need following operation: Move the mounting head above the rim; Insert the lifting lever in the clearance between the bottom tire bead and the rim, have the tire hung on the mounting head(Fig 16); Tread the power supply pedal to rotate the turntable. With the help of the mounting head, the tire is detached completely.**

### 10.4.3. Mounting the tire

Lubricate the tire bead and rotate the turntable, mount the bottom bead with the mounting head; Pull the hex rod out, press the upper bead under the mounting head 5mm with the tire pressing roller, rotate the rotating arm and move the tire pressing block above the tire; Don't touch with the rim in the operation, or it causes damage on the rim due to friction.

Tread the power supply pedal to rotate the turntable and the tire pressing block, lower the help arm to press the tire under the rim. Mount the tire with the mounting head. Please pay attention to the safety in the process of operation. (Fig 14)

### 11. Inflating the tire :

Importance: It is very dangerous during inflating operation, take carefully and comply with instruction. When inflating, it will turn to be extremely dangerous if problems happen to tyre or rim. The possible burst force tire goes upward and outward, the big power may cause injury or death of the operator or the people around.

Tyre may burst caused by following:

- 1) The wheel rim and the tyre are not of the same size;
- 2) The tyre or the wheel rim is damaged;
- 3) The pressure of tyre inflation is over the max. pressure recommended by manufacturer;
- 4) The operator fail to comply with the safety regulation;




Fig 15

Please operate as follows:

- 1) Remove the valve cap from the valve stem;
- 2) Check to make sure the air nozzle is pressed down completely over the threads of the valve stem.
- 3) Check to make sure that the tyre and the wheel rim are of the same size;
- 4) Lubricate both the tyre bead and the wheel rim, additional lubrication is required if needed;
- 5) Inflate the tyre with break, while inflating, check the pressure listed on the pressure gauge, also check whether the bead is fixed or not. Repeat operation above until the bead is secured; you need take special steps when inflating convex rim or double convex rim;
- 6) Continue inflating and check the air pressure frequently until to reach the required pressure.

Note: Never exceed the max. inflation pressure given by the tyre manufacturer.

Keep hands and your body away from inflating tyres.

Only specially trained persons are allowed to perform the operations, do not allow other to operate or be near the tyre changer.

### 12. Moving machine:

Please use forklift to move the machine. Disconnect the tyre changer from the electricity power supply and pneumatic power supply, lift the base board and insert the feet of forklift. Then mount the tyre changer machine to a new position and fix it tightly.

Note: the place chosen for fixing the tyre changer must meet the safety regulation.




Fig16

### 13. Maintenance:

Caution: only the professional persons can do the maintenance. To prolong the machine's life, maintain the machine timely according to the manual. Otherwise, it will impact the reliability of the machine or even cause injury to operator and others nearby.

Caution: before performing any maintenance, disconnect the tyre changer from the electric power supply and pneumatic power supply, and depress the Jaws open and close Pedal or Turntable Rotation Pedal for 3~4 times to evacuate all compressed air from the machine. Damaged parts must be replaced by professional persons with the spare parts provided by manufacturer.

- Clean the machine once every day after work. Clean the dirt on the turntable with diesel oil once per week and lubricate the slides and clamps.
- Following maintenance must be done at least once per month:

Check oil level in Oil Fog Maker, please be filled with SAE30# oil if need.

Unscrew with hex wrench (E). Based on connection of compressed air, first to depress Jaws open and close Pedal or Turntable Rotation Pedal 5-6 times, and then check whether oil in Oil Fog Maker drops down a drip of oil. For continuous operation, depress twice every time, drop down a drip of oil, otherwise adjust the screw (D) that controlled oil enter with minus screwdriver. (Fig 16)




Fig 17

Note: After the first 20 days of use, retighten the jaws with tightening screws (B) on the Turntable (Fig 17)

Note: in the event of turntable lose power, check to see if the belt is tight as follow steps:

Remove the left side cover by unscrewing the screws; adjust two screws located on the motor support, keep a suitable distance between motor support and motor base; tight the screws for the belt tension.(Fig 18)

Caution: please disconnect the machine from electric power supply and pneumatic power supply.

Note: If Vertical Arm not be locked or not meet the requirement that 2-3mm from the bottom of Mounting head/demounting head to rim, please adjust Hexagonal Locking Plate, refer to Fig 19 and adjust the (X).

Note: In order to achieve the reliability of jaws and Bead Breaker shovel, operate as follows to keep their valves clean:

1. Remove the left side cover of the machine body by unscrewing the two screws;
2. Loosen the valve mufflers (A) which belong to Jaws open and close Pedal and Bead Breaker Pedal; **(Fig 23)**
3. Clean the mufflers with compressed air, please replace it referring to the spare parts list if it is damaged. **(Fig 23)**




Fig 18




Fig 19




Fig 20

**14. Trouble shooting table:**


Problem	Reason	Solution
The turntable rotate just in one direction or can't rotate.	Reverse Switch broken	Replace the Reverse Switch
	Belt broken	Replace the belt
	The Motor's malfunction	Check the motor cable or terminal block wire; Replace the motor if it was broken.
Demount or fix the wheel, the turntable can't lock (spin with wheel); The jaws delay to open/close; The turntable locks the rim incorrectly.	Leakage of Air network	Check all the parts on the air network.
	The clamping cylinder can't work.	Replace the cylinder piston.
	Worn jaws	Replace the jaws.
	Broken washers of the chuck cylinder	Replace it.
The mounting head/demounting head always touch the rim during operation.	The locking plate incorrectly adjust or unqualified.	Replace or adjust it.
	Screws on the chuck loose; the Vertical Arm can't be locked by Locking Plate	Tighten the screws; replace the Locking Plate.
The Bead Breaker Pedal and Jaw open and close Pedal can't turn back to the original position.	pedal spring broken	Replace it.
The Bead Breaker shovel operates difficultly.	Jammed silencer	Clean it or replace it.
	The washer on the Bead Breaker cylinder is broken.	Replace it.

**14.Spare parts ordering guide**

- 1、 First get the damaged or the product samples which have to stock up, and confirm the quantity of parts.
- 2、 In order to avoid the mistakes,confirm the specification of the parts which need to replace.

Confirmation as follows: According to the using range and position of the parts,find the corresponding code from the exploded drawing and record the full code(section 16).For the customers with many models,if the same accessories in Different models ,the ERP information coding shows different serial number,for example,lifting lever: the ERP information coding is C-200-580000-0,the series number in different models,shows12.200-12 or other forms of series number,that belong to the same accessories.So full in the list can be classified into the spare parts category.

For example,we need to buy crow bar ,because crow bar always placed in crow bar set inside,so we locate the exploded drawing as below:



See number “12” from the figure, then find all the messages from the list, and record it.  
As the following figure

11	B-027-060401-0	Grounding screw M6x40
12	C-200-580000-4	Lifting lever
200-13	C-200-510000-0	Bead breaker arm spring

Record the information

12	C-200-580000-4	Lifting lever
----	----------------	---------------

### 3、Collect the details information of the products

For example

NO.	Order number	Name	Quantity	purchasing date
12	C-200-580000-4	Lifting lever	2	2009.6.25

4、Contact our spare parts department to confirm the order information.


5、Confirm the order information are correct, then according to the order of supply and demand information delivery to you timely

**16. Remark: Advise to fill in the purchasing time of the machine into the order form so that confirm the manufacturing information of the equipment.**


序号查询	订货号	零件名称	序号查询	订货号	零件名称
300-10	C-300-500000-0	Rubber mat	311	S-005-168115-0	V- seal 185×168×10.8
226	S-005-020075-0	V- seal 20*28*7.5	200-321	S-000-175500-0	O- seal Ø173.4×5.3
227	S-000-063265-0	O- seal 63*2.65	331	S-000-019262-0	O- seal Ø 19.6*2.62
200-228	C-200-540000-0	Tilting cylinder piston Ø70	200-426	S-060-016000-1	Reverse switch
232	S-000-019262-0	O- seal Ø19.6×2.62	521	S-000-030355-0	O- seal Ø 30*3.55
306	S-000-016265-0	O- seal Ø 16*2.65	200-532	S-000-059262-0	O- seal 59.9*2.62
307	S-000-020265-0	O- seal Ø 20*2.65	604	S-042-000686-0	Tyre changer belt A-28
200-308	S-000-180500-0	O- seal 180×5	811	S-033-330000-0	Oil fog maker3300

**Remark: The parts in this list are vulnerability consumable spare parts , if you have other parts order please query the accessories instruction manual.**



## 17. Exploded drawing:




700-1	CX-700-010000-0	Machine body 700
700-2	CX-700-080000-0	Pedal front cover
321-3	CX-321-020000-A	Left cover
4	B-010-060401-0	Hex socket head bolt M6×40
5	B-040-061412-1	Flat washer Ø6*14*1.2
6	B-014-080251-0	Outer hex bolt M8x25
7	B-010-060101-0	Hex socket head bolt M6×10
8	B-040-061412-1	Flat washer Ø6*14*1.2
9	C-000-001020-0	Rubber foot buffer
221-10	C-221-500000-0	Bead breaker buffer
11	B-027-060401-0	Grounding screw M6x40
12	C-200-580000-4	Lifting lever
200-14	C-200-510000-0	Bead breaker arm rubber
200-15	C-200-470000-0	Oil-water box
16	B-010-080201-0	Hex socket head bolt M8x20
17	B-040-081715-0	Flat washer Ø8*17*1.5
221-20	CX-221-010106-0	Tilting seat
221-21	C-221-820000-0	Tilting protect cover
700-7	CX-7000-080400-0	Head board
700-8	B-010-050121-0	Hex socket head bolt M5x12




79	S-012-010806-0	Quick union 1/8-Ø6	221-147	C-221-350200-0	Tilting cylinder piston rod
80	C-221-250600-0	Locking cylinder plate	148	B-001-080001-0	Self-locking nut M8
81	CX-231-190000-0	Horizontal arm locking plate	221-149	C-221-350100-0	Tilting cylinder cover without handle
82	B-040-081715-1	Flat washer Ø8*17*1.5	150	S-005-020075-0	V seal Ø20*28*7.5
83	C-221-410000-0	Horizontal arm locking spring	221-151	C-221-550000-0	Tilting cylinder piston
231-84	CX-231-240000-0	Horizontal arm block	152	B-004-120071-0	Nut ( silver ) M12*1.5*7
85	B-014-080201-0	Outer hex bolt M8*20	221-153	C-221-350500-0	Tilting cylinder barrel
86	B-001-080001-0	Self-locking nut M8	154	S-010-010806-0	Straight union 1/8-Ø6
87	B-001-120001-0	Self-locking nut M12	221-155	C-221-350300-0	Titling cylinder cover with handle
88	B-040-122520-1	Flat washer Φ 12*25*2	221-156	CX-221-351000-0	Tilting cylinder piston rod cover
89	B-040-122520-1	Flat washer Φ 12*25*2	221-157	C-221-350700-0	Titling cylinder rubber sheath 1
90	C-221-230000-0	Locking spacer	159	B-040-104030-1	Flat washer 10*40*3
231-91	C-231-780000-0	Horizontal arm protection back cover	161	B-001-120001-0	Self-locking nut M12
231-92	B-007-100161-0	Hex socket head bolt M10*16	163	B-014-120651-0	Outer hex bol tM12x65
231-93	B-007-080161-0	Hex socket head bolt M8*16	221-169	CX-221-220000-0	Hex locking board 221
231-94	C-231-251300-0	Column end pulley	221-171	C-221-790000-0	hose guide
231-95	C-231-251400-0	Pulley Pin	221-172	CW-105-021102-0	Complete titling cylinder
231-116	C-231-480000-0	Horizontal arm protection back cover	700-173	CX-7000-250000-0	Column
119	B-010-100501-0	Hex socket head bolt M10*50	231-175	C-231-460000-0	Titling Column back cover
228-120	C-228-490000-0	Vertical arm cap 228	231-174	C-231-450000-0	Column protection cover
228-121	C-228-390000-0	Vertical arm spring	176	B-024-050161-1	Cross head screw 5*16
128	C-221-200000-0	Shock absorber	177	CX-221-260000-0	Column shaft
129	B-010-060351-0	Hex socket head bolt M6x35	221-180		"Complete locking cylinder,T-union"
221-130	P-120-260000-0	guide pulley	221-182	C-221-090100-0	Complete locking cylinder piston
131	B-010-060161-0	Hex socket head bolt M6x16	221-183	S-005-050065-0	V seal Ø60*50*6.5
132	S-017-010806-2	T-union 1/8-2*O6	221-184	S-000-006300-0	O seal Ø6*3
221-133	CX-221-160000-0	Vertical arm	185	B-010-060551-0	Hex socket head bolt M6x55
221-134	C-228-520000-0	Vertical arm washer	221-186	CX-221-090200-0	Locking cylinder cover Ø60
135-3#	CW-113-020303-0	Complete Mount/demount head 3#	221-187	S-000-052200-0	O seal 52X2
136	CX-200-170000-0	3# Mount/demount head protection washer	190	C-221-210100-0	Pneumatic handle switch plate
137	B-014-100251-0	Outer hex bolt M10x25	191	C-221-210200-0	Pneumatic handle valve rod
200-138	CX-200-150200-0	Mount/demount head pulley	192	C-221-210500-0	Pneumatic valve rod cap
200-139	C-203-150100-3	Mount/demount head B03#	193	C-221-210300-0	Pneumatic handle cover
200-140	C-200-150400-0	hex round pin	194	C-221-210400-0	Pneumatic handle spacer
141	B-007-120161-0	Hex socket head bolt M12*16	195	S-000-007265-0	O seal 7.5*2.65
142	CW-119-021100-0	Complete Pneumatic locking switch	196	B-055-080001-0	Snap ring Ø8
143	B-010-060161-0	Hex socket head bolt M6x16	197	S-010-010806-0	Straight union 1/8-Ø6
145	S-000-068353-0	O seal Ø68.26*3.53	221-198	C-221-400000-0	Hex locking board spring
221-146	C-221-350900-0	Tilting cylinder threaded			




202E-201	CX-202-130100-0	Turntable
202	CX-221-120300-0	Jaw sliding plate(optional)
221A-203	CX-221-120000-A	Jaw cap assembly
300-204	C-300-570000-0	Jaw 300
205	CX-200-140000-0	Big washer
206	B-050-160000-0	Spring washer Ø16
207	B-014-160401-0	Outer hex bolt M16×40
208	C-200-440000-0	Turntable cap
221A-209	CX-221-310000-0	Connection rod assembly 615
221-210	CX-221-280000-0	Square turntable 615
211	CX-200-290000-0	Square turntable washer
212	B-055-650001-0	Snap ring Ø65(shaft)
221A-214	CX-221-110000-A	Jaw slide guide with pin
215	B-040-122520-1	Flat washer Ø12X25X2
216	B-055-120001-0	Snap ring Ø12(shaft)
217	B-014-120801-0	Hex socket head bolt M12×80
218	B-046-122050-1	Teeth locking washer Ø12×1
219	B-040-123030-1	Flat washer Ø12X30X3
200-220	CX-200-300000-0	Connection rod nut
221A-221	CX-221-110100-A	Jaw slide guide without pin
221-222	C-221-100400-0	Threaded connection rod 393
221-223	C-221-100200-0	Clamping cylinder piston rod 400
200-224	C-200-100100-0	Clamping cylinder cover without handle
225	S-011-010808-0	Straight union 1/8"-Ø8
226	S-005-020075-0	V- seal 20*28*7.5
227	S-000-063265-0	O- seal 63*2.65
200-228	C-200-540000-0	Clamping cylinder piston Ø70
229	B-040-122520-1	Flat washer Ø12X25X2
230	B-004-120071-1	Nut M12X7X1.75
221-231	C-221-100500-0	Clamping cylinder barrel 360
232	S-000-019262-0	O- seal Ø20X2.65
200-233	C-200-100300-0	Clamping cylinder cover with handle
234	S-018-010808-0	Quick union 1/8-Ø8
235	B-001-080001-0	Self-locking nut M8
221-236	CW-105-021101-0	Complete clamping cylinder
300-251	C-300-730000-0	Jaw jacket
202E-237	CW-104-02020-1	Complete square turntable



231-13	C-231-360000-0	Bead breaker arm spring	231-322	CX-231-030000-0	Enlarge bead breaker arm 231
200-301	B-010-140301-0	Hex socket head bolt M14*30	200-323	CX-200-040000-0	Bead breaker arm pin
302	B-001-060001-0	Self-locking nut M6	200-324	CX-200-050600-0	Bead breaker cylinder rotating pin
303	S-018-010408-0	2-way Union (90°) 1/4-Ø8	325	B-040-122520-1	Flat washer Φ 12*25*2
304	B-004-160001-1	Self-Locking Nut M16X1.5	326	B-001-120001-0	Self-locking nut M12
305	B-040-162820-1	Flat washer φ16*28*2	327	B-040-083030-1	Flat washer Ø8*30*3
306	S-000-016265-0	O- seal φ16*2.65	328	B-050-080000-0	Spring washer Ø8
307	S-000-020265-0	O-seal φ20*2.65	329	B-014-080201-0	Outer hex bolt M8*20
200-308	S-000-180500-0	O-seal φ180*5	330	S-011-010808-0	Straight union 1/8-φ8
200-309	CX-200-050500-0	Bead breaker cylinder cover assembly D186	331	S-000-019262-0	O- seal φ19.6*2.62
200-310	C-200-050100-0	Bead breaker cylinder piston rod	231-332	CX-231-030900-0	Enlarge bead breaker arm rotating washer φ16.5*40*8
311	S-005-168115-0	V-seal φ185*168*10.8	231-333	CX-231-030800-0	Enlarge bead breaker arm rotating shaft
200-312	C-200-050200-0	Bead breaker cylinder piston	200-334	CW-108-020000-0	Complete bead breaker cylinder
200-313	CX-200-050300-0	Bead breaker cylinder barrel	350	CW-112-209800-0	Bead breaker cylinder exhaust valve
314	B-010-060161-0	Hex socket head bolt M6x16	351	S-012-010808-0	Quick union 1/8- Ø 8
200-315	CX-200-070000-0	Bead breaker shovel assembly	352	C-098-600200-0	Bead breaker cylinder exhaust valve cover
316	B-010-120901-0	Screw	353	C-098-600400-0	Seal Washer
317	B-004-160001-1	Self-Locking Nut M16X1.5	354	C-098-600300-0	Bidirectional Seal
318	U-006-000001-1	Bronze stripes (large iron cylinder with)	355	C-098-600100-0	Bead breaker cylinder exhaust valve barrel
319	B-050-140000-0	Spring washer Ø14	356	S-023-010401-6	Muffler 1/4
320	B-055-160001-0	Snap Ring Ø 16	357	S-010-010408-0	Quick straight union 1/4- Ø8
200-321	S-000-175500-0	O-seal φ173.4*5.3	200-370	C-200-070600-0	Bead breaker shovel protection cover(optional)




300-401	C-300-060400-0	Reverse switch pedal	429	B-040-040000-1	Flat Washer Ø4
300-402	C-300-060300-0	5-way valve pedal(right)	430	B-024-040161-0	Corss Round Head Screw M4X16
300-404	C-300-060200-0	5-way valve pedal(left)	200-431	C-200-530000-0	Reverse switch handle
405	B-055-120001-0	Snap Ring Ø12	432	B-001-060001-0	Self-locking nut M6
406	B-040-122520-1	Flat washer $\Phi$ 12*25*2	433	B-040-030000-1	Flat Washer Ø3
407	B-024-040301-0	Cross Head Screw M4X30	434	B-024-030161-0	Corss Round Head Screw M3*16
408	B-040-040000-1	Flat Washer Ø4	200-435	CX-200-060600-0	Pedal Connection Rod
409	B-001-040001-0	Self-locking nut M4	436	B-001-080001-0	Self-locking nut M8
410	B-001-080001-0	Self-locking nut M8	437	CX-200-060700-0	Pedal front shaft
411	B-040-081715-1	Flat washer $\Phi$ 8*17*1.5	438	B-004-080001-0	Nut M8
200-412	C-200-061300-0	Cam connection rod	439	C-200-370000-0	Pedal twist spring
300-413	C-300-060100-0	Pedal support board	440	B-010-080501-0	Hex Socket Head Bolt M8X50
200-414	C-200-380000-0	Pedal Spring	441	B-010-080201-0	Hex socket head bolt M8*20
200-415	C-200-061500-0	Cam	442	S-012-010808-0	Quick union 1/8- Ø 8
200-416	C-200-810000-0	Cam washer	443	S-012-010806-0	Quick union 1/8-Ø6
417	B-010-060201-0	Hex Socket Head Bolt M6X20	445	S-016-010808-2	Quick T-union 1/8-2* Ø 8
418	B-040-061210-1	Flat washer Ø 6X12X1	200-449	C-200-060901-0	5-way valve barrel
420	B-019-290121-0	Cross Head Self Tapping Screw ST2.9*12	200-451	C-200-061100-0	5-way valve cover
200-421	CX-200-060500-0	Cam cover	452	B-024-290-121-0	Cross head screwST2.9*14
423	CW-110-020001-0	"5-way valve (T-union,without rod)"	453	S-023-010801-0	Muffler 1/8
200-424	C-200-061400-0	Reverse Switch Cover	200-455	CX-200-061200-0	5-way valve rod
425	B-004-040001-0	Hexagon nut M4	200-456	C-200-061000-0	5-way valve rod spacer
200-426	S-060-016000-1	Reverse switch	457	S-000-012400-0	O-seal $\phi$ 12*20*4
427	B-010-060201-0	Hex Socket Head Bolt M6X20	462	S-030-010806-0	Throttle valve
428	B-040-061210-1	Flat washer Ø 6X12X1	470	CW-110-021102-0	"Tilting 5-way valve,without rod"




A04	S-015-000008-3	Quick T-union 3* Ø 8
A44	B-010-060161-0	Hex socket head bolt M6x16
A48	S-017-010808-2	Quick union 1/8-2*φ8
200-531	CX-200-430100-0	Rotating valve casing(plastic)
200-532	S-000-059262-0	O-seal φ59.99*2.62
200-535	CX-200-430200-0	Rotating valve mandrel
537	S-035-055080-0	Flexible air hose φ8*10M
A41	S-011-010808-0	Straight union 1/8-φ8
548	B-007-040061-0	Bolt M4*6
200-540	CW-106-020000-0	"Complete Rotating valve,plastic"


300-526




300-501	C-300-320302-0	Gear box lower cover
502	S-040-030204-0	Bearing 30204
503	S-005-020080-1	Gear Seal φ20*35*8
200-504	C-200-320500-0	Gear Belt pulley U200
505	B-014-080251-0	Outer hex bolt M8*25
506	B-065-006020-0	Key washer 6x20
200-507	C-200-320400-0	Worm rod
508	S-040-006010-0	Bearing 6010
200-509	C-200-320200-0	Worm gear shaft
200-510	C-200-320100-0	Worm gear U200
200-511	CZ-200-320600-0	spacer
512	B-014-100551-0	M10*55 (全牙)
513	B-050-100000-0	Spring washer Ø10
200-514	B-060-006020-0	Pin 6X20
515	B-040-102020-1	Flat washer φ10*20*2
516	B-010-060201-0	Hex Socket Head Bolt M6X20
517	B-040-061412-1	Flat washer Ø 6*14*1.2
300-518	C-300-320301-0	Gear box upper cover
519	B-065-010040-0	Key washer 10x40
520	B-065-014040-0	Key washer 14x40
521	S-000-030355-0	O-seal Ø 30*3.55
200-522	C-200-320700-0	oil resistant seal
200-526	CW-107-020001-0	Complete gear box




200-504	C-200-320500-0	Gear Belt pulley
601-MC	S-050-220110-5	Motor 220V/50HZ
601-MY	S-050-230075-0	Motor 220v
200-602	CX-200-330000-0	Motor Belt pulley
603	B-007-080121-0	Hex socket head bolt M8×12
604	S-042-000686-0	Tyre changer belt A-28
605	B-014-080651-0	Outer hex bolt M8X65
606	B-040-083030-1	Flat washer Ø8X30X3
607-80	S-063-008000-0	Capacitor 80µf,110V
607-50	S-063-005000-0	Capacitor 50µf,220V
608	B-040-102020-1	Flat washer Ø10X20X2
614	C-200-560000-0	Motor rubber washer
200-615	CX-200-340000-2	Motor support
617	B-050-080000-0	Spring washer φ8
200-618	C-200-560000-0	Motor rubber buffer



701W	S-038-000200-0	Inflating gun indicator
702	C-200-900000-0	Rubber connection hose
703	S-025-104008-0	Notch nut
704	S-025-104008-0	Straight union 1/4-1/4
705	B-040-132420-1	Flat washer Ø13
706	S-030-010400-2	Pressure adjust valve
707	S-012-010408-0	Quick union 1/4-Ø8
708	CW-090-000201-0	Complete inflating gun




811	S-033-330000-0	oil fog maker 3300
813	S-018-010408-0	2-way Union (90°) 1/4-Ø8
820	CW-114-033000-0	Complete oil fog maker 3300
811	S-033-330000-0	oil fog maker 3300



F6601		Column assembly	F5628	B-010-050101-0	Hex socket head screw M5*10
F5602	CX-007-020000-0	Guide rail	F5629	B-010-100251-0	Hex socket head screw M10*25 (optional )
F5603	B-010-080251-0	Hex socket head screw M8*25	F5630	B-024-040161-0	Corss Round Head Screw M4X16
F6607		Support assembly	F5631	CX-056-080000-0	Connecting pin
F5609	CX-056-010700-0	Junction plate of cylinder cover	F5632	B-010-120551-0	Hex socket head screw M12*55
F6610		Raise-fall cylinder 006	F5633	C-056-090000-0	Axle
F6611		cylinder cover	F5634	C-006-210000-0	Pentagon handle M10
F5615	B-001-060001-0	Self-locking nut M6	F6635		Arm base assembly
F5616	B-010-060301-0	Hexagon socket head bolt M8*25	F5636	CX-007-040000-0	Abrasion inner tableting
F5617	C-056-140000-0	Tire pressing head rotating shaft	F5637	CX-007-070000-0	Friction plate isolation block
F5618	C-008-090100-0	Tire pressing head (upper)	F5638	CZ-007-080000-0	Counter vane locating pin
F5619	B-045-000027-0	Lock washer	F5639	U-006-000001-2	Guidance tape
F5620	B-004-270001-1	Round nut M27	F5640	CX-007-050000-0	Counter vane locating pin
F5621	CX-056-070000-0	Rotating arm assembly 2	F5641	B-001-100001-0	Self-locking nut M10
F6622		Rotating arm assembly1	F6645	C-008-080000-0	Tire pressing pulley
F5623	C-007-181000-0	Control valve protection cover	F6649		Tire lifting rod assembly
F5624	B-017-040301-0	Cross-round head screw M4X30	F6650		Tire pressing rod assembly 066
F5625	B-004-040001-0	Hexagon nut M4	F5651	B-040-083030-1	Flat washer Ø8*30*3
F5626	S-030-010818-0	Handle valve	F6658		Connecting plate
F5627	CX-056-120000-0	Control panel assembly	F5660	C-238-201501-0	Adjust handle

18. Circuit diagram:



19. Pneumatic drawing:

